

# How to use Comp Door Twist Guides

Document Number	TDC-064	
Title	How to use Comp	Door Twist Guides?
Part Code	N/A	
Version	V1	
Description	Guide showing how to check if lock side frame has been lined up with the leading of the door slab	
Method	N/A	
Pre-Checks	Ensure all parts are available	
Steps		

## Step 1


Open the door and place the two guides at the top and the bottom of the door. Place above and below the locking strip.

Please ensure the chamfer part of the guide is on the external face if the door is opening inwards and on the internal face if the door is opening outwards.



#### Step 2

Now that the guides are fitted to the top and the bottom of the door slab. From the outside, pull the door towards the outer frame if the door is opening inwards. And from the inside pull the door towards the outerframe if the door is opening outwards.



## Step 3

Once the door is tight to the inside face of the frame.

And the chamfer of the guide is contacting the internal face of the frame.

You should see that the twist guides touch the top and the bottom at the same time.



### Step 4

If one touches the frame before the other. This then shows that there is twist in the outerframe at the top or at the bottom.



#### Step 5

The final step when using the twist guides. Is if one of the guides touched the top or the bottom of the frame first.

This indicates the other one, that part of the frame is leaning too far in/out. Whether it's the top or the bottom, the frame will need to be adjusted accordingly to ensure the door slab runs parrallel with the woolpile gasket on the frame.



